

AUDIO — audio selection menu

TV/RADIO — switch between TV and RADIO mode

MUTE — mute the audio

TTX — teletext service or text entry menu

HD — change temporary video mode (note 2)

HD long — HDMI CEC setup (note 2.5)

PAGE DOWN — down the page

FAV — show favourite services from bouquets

FAV long — IMDB details

SAT — show available satellites

SAT long — assignable

UP — show channels and position on previous one

DOWN — show channels and position on next

LEFT — switch to previous channel

NEXT — switch to next channel

All of them — navigate thru options

OK — confirm selection / show channel status

OK x 2 — show extended channel info



POWER — switch on and off stand by mode

POWER long — show power state menu (note 1)

SUBT — select subtitles if available

V SIZE — select video scaling

V SIZE long — assignable

PAGE UP — up the page

0—9 — direct channel selection or SMS like text entry

MENU — main menu or plugin menu if available

I (INFO) - event info

I (INFO) long - EPG and event relates setup

EXIT — exit menu or hide info messages

EPG — single channel EPG info

EPG long — multi channel EPG info

RED — timeshift

GREEN — channel subservice menu (<< and >>)

YELLOW — audio and subtitles options

BLUE — show extensions

BLUE long — PowerBoard Center

All of them — actions in menus

TIMER — editor for timers/recordings

MEDIA — open Media Portal

MEDIA long — Media Player

REC LIST — show recordings or movies

PREVIOUS — previous entry or zap to previous channel
in history or move left in text entry fields

REWIND — backward skip, subservice previous

FORWARD - forward skip, subservice next

NEXT - next entry or zap to next channel in history or
move right in text entry fields

Notes:

1 — POWER long: action is adjustable in Menu>Setup>System>User
Interface>Action on long powerbutton press

2 — HD: useful for fine, temporary video playback adjustment. Available
video modes (like 24p, 25p etc.) depend on your TV capabilities. Result-
ing picture quality is related to quality of STB and TV scalars.

2.5 — HD long: not all TVs support this feature

3 — USB: Temporary eject, use USB long for permanent removal of
USB media device.



VOL plus — increase sound volume

VOL minus — decrease sound volume

LIST— show channel selection menu

RECALL — zap thru history

PORTAL — open box portal (tv/radio/recordings)

CH plus — show channels

CH minus - show channels

PLAY — start playback or start time shift

PAUSE — pause playback or start timeshift

STOP — stop playback or timeshift stop

RECORD — instant recording

OPT — show help

OPT long — PowerBoard EMU manager

SLEEP — sleep timer configuration

SLEEP long — restart active (or sleepy) EMU

USB — safely remove USB device (note 3)

USB long — remove USB media via PowerBoard device
manager (for permanent removal)

DELAY — audio delay

DELAY long — setup audio delay options